



- ✓ DIN 835 - 938
- ✓ DIN 939 - 940
- ✓ UNI 5909-5919

TIR

VITI PRIGIONIERE
STUD BOLTS
STIFTSCHRAUBEN
GOUJONS



Dimensions in mm										
d Filetto/Thread	M3	M4	M5	M6	M8	M10	M12	M14	M16	M20
d1		4	5	6	8	10	12	14	16	20
l	12	10+40	12+50	14+70	16+100	18+120	22+140	25+160	28+170	35+200
b	$l \leq 125$	14	16	18	22	26	30	34	38	46
	$125 < l \leq 200$	-	-	-	-	-	36	40	44	52
	$l > 200$	-	-	-	-	-	-	-	-	-
e	X = rad.corta (DIN 938)	4	5	6	8	10	12	14	16	20
	Y = rad.media (DIN 939)	6	7	9	12	15	18	20	22	28
	W = rad.lunga (DIN 835)	8	10	12	16	20	24	28	32	40
	T = rad.extra lunga (DIN 940)	10	13	15	20	25	32	35	40	50

NOTE: aggiungere alla fine del codice la lettera corrispondente radice e desiderata
to indicate the root you need, add the corresponding letter to the end of the code

CODE EXAMPLE:

400 + material + diam + thread + length + color + root
 TIR M6x20 AI7075 white rad.corta= 400106020BX